

Quantum Sail Design Group
J-80 Quick Guide

<u>Uppers</u>	<u>Lowers</u>	<u>Int.</u>		<u>Wind Speed</u>
- 2 turns	-2 turns	0		0-6 knots
26 (<i>Loose Pro</i>)	18 (<i>Pro</i>)	36(<i>A</i>)	BASE	5-12 knots
+3 turns	+3 turns	+2 turns		12-22 knots

- Mast chocked aft, with block in front of spar.
- Mast aft to aft bulkhead measurement: 9 _ “
- Mast forward to forward bulkhead measurement: 6 3/8 “
- Rake: 37’ 7” to transom top/aft edge
- Headstay: 32’11” (33’ max)
- Backstay: 28’6 _ ” long
- Backstay legs: 8’9 3/8” each
- Jib leads:
 - setting # 1 hole forward of int. shrouds (0-8knots/chop)
 - # 2 even w/ int. shrouds (6-14 knots)
 - # 3 one hole forward of 4th screw aft (12-18)